Epson 2250U Projector Instructions

Works with iPhone/iPad/Android Phone/Pad/Mac Computer/Windows Computer

Wireless Connection

(Flip sheet over for Cable)

On Your Device

1. Connect to "Juneau Yacht Club" wireless network

using password: jacksparrow

1. Download "Epson iProjection" app as follows

Windows Computer: https://ftp.epson.com/drivers/iProj 4.01.exe
Mac Computer: https://ftp.epson.com/drivers/iProj 4.01.exe
For iPhone/iPad or Android phone, scan QR code at bottom of page

2. Install and Open "Epson iProjection" app

On Projector

- 1. Plug in **Power Cord** to Projector
- 2. Open **Shutter** (A)
- 3. Press "On/Off" U button (B)
- 4. Adjust Focus & Tele (C) & center image on screen
- 5. Change Source (if necessary) to LAN

On Your COMPUTER (View on projected image)

- 1. If not already on "Advanced Connection Mode", click on that option
- 2. Click box by "JYCProjector" and then "Connect" at bottom of window
- 3. Screen should be mirrored. Use your device to manipulate presentation

-OR-

On Your PHONE/PAD

- 1. In Epson iProjection, click on "JYCProjector" if it appears
- 2. If it doesn't appear, click "QR Code Connection" & aim camera at screen image
- 3. Click on "Mirror device screen", "Start mirroring", "Start Broadcast"
- 4. Screen should be mirrored. Use your device to manipulate presentation

To Stop

- 1. On COMPUTER, in **Epson iProjection** app, click on "Stop" N, then click on "Leave"
- 2. On PHONE/PAD, in **Epson iProjection** app, click on **Disconnect**
- 3. On PROJECTOR or Remote, Click "On/Off" U button (B)
- 4. Close lens Shutter (A)
- 5. Unplug power cord, let projector cool. Place projector, remote, & cord in bag.





Android QR Code



Epson 2250U Projector Instructions

Works with iPhone/iPad/Android Phone/Pad/Mac Computer/Windows Computer

Cable Connection

(flip sheet over for Wireless)

On Projector

- 1. Plug in **Power Cord** to Projector
- 2. If your Device has a **HDMI output**, use an HDMI data cable to **HDMI1** port on the projector.
 - OR -
- 3. If your Device has a **Lightning**, **USB-C**, or **Mini USB** input used on phones or pads, plug in **Red-Ended Data Cable** to **HDMI1** on projector and other end to your device using (1) built-in Mini USB cable end or (2) Lightning or (3) USB-C removable adapters which can be plugged onto Mini USB cable end.
- 4. Plug in White Power Block to A/C power and Red USB-A Cable into Power Block. (Ignore "Download App" QR Code for DGKDH340DR006HP8MV001)
- 5. Turn on your **Device** such as phone/pad/computer
- 6. Open Shutter (A) on Projector
- 7. Press "On/Off" U button (B) on Projector
- 8. Adjust Focus & Tele (C) & center image on screen
- 9. Change **Source** on Remote or Projector (if necessary) to **HDMI1** (or another appropriate input option if you use your own cable such as RS-232 or RCA)

On Your Device

1. Screen should be mirrored. Use your device to manipulate presentation

To Stop

- 1. Unplug **Data Cable**
- 2. On Projector or Remote, Click twice on "On/Off" (b) button (B)
- 3. Close lens **Shutter** (A)
- 4. Unplug cables, let projector cool. Place projector, remote, & cables in bag.